

ZK Building, Wuhe Road, Gangtou, Bantian, Buji Town,
Longgang District, Shenzhen China 518129

Tel: +86 755-89602345

Fax: +86 755-89602394

www.zkteco.com




Copyright©2019 ZKTECO CO., LTD. All rights reserved.

5 Delete Fingerprints




Under the locked state, push the U-type shackle to its lowest position (just a little bit down). Touch the fingerprint sensor, **blue and red LED** will light, which means the lock enters deletion mode.



Then loosen the shackle, keep pressing with the administrator fingerprint on the sensor until the blinking **red LED** turns to **green LED**, which means all fingerprints except the first two (administrator) fingerprints are deleted. Repeat the above delete operation again, all the fingerprints will be deleted.
Note: Don't move off the fingers when red LED blinks, otherwise the deletion will interrupt.

6 Low Power Alert and Recharge



When charging, remove the silicone USB plug, insert the USB cable and link to any PC/tablet or charge pal. **Red LED** is blinking while charging. After about 60 minutes of charging, **green LED** will light, which means the charging is completed.


When the system detects low power, **yellow LED** will blink when you touch the fingerprint sensor. You can still open the lock for about 50 times when yellow LED blinks at first time. If the battery is totally out of power, you need to link the lock to a charge pal or other portable power supply before unlocking it, then remember to recharge it.

User Manual


Padlock

Version: 1.0


Date: April 2019



1 Register Fingerprint




Touch the fingerprint sensor to start, then **blue LED** will blink, which means the lock enters the registration mode.



Press with one finger on the sensor, move the finger off when **green LED** lights. Then repeat two more times until the fingerprint is registered. Finally, the padlock will turn off automatically.


Note: The maximum fingerprint capacity of lock is 10. **The first two fingerprints belong to the administrator group, they have the right to register or delete other fingerprints.**

2 Verify and Unlock




Press with one registered finger on the sensor, **green LED** will light if the verification is correct, then the lock will unlock automatically. If **red LED** lights, please try again more carefully.

Note: After seven failed verification, the lock will turn off automatically.




3 Lock up



Press down the U-type shackle to the hole, and it will be locked up.


4 Add More Fingerprints



Before adding new fingerprints, use one of the administrator fingerprints to unlock the lock. Under the unlocked state, keep pressing about three seconds until **green LED** blinks.



Then move off the finger and **blue LED** will blink, which means the lock enters registration mode.



Use the new fingerprint to repeat the above registration operation.

