Installation Guide

ZKBioAccess

Version: 1.0
Date: January 2019

Contents

Before Installation

Configuration Requirements

CPU: Master frequency of 2.0G or above

Memory: 4G or above

Hardware: Available space of 10G or above. We recommend using NTFS hard disk partition as the software installation directory

Monitor Resolution: 1024*768 pixel or above

Operating System

Supported Operating Systems: WindowsXP/ Windows7/ Windows8/ Windows8.1/ Windows Server 2008(32/64)

Supported Databases: PostgreSQL

Recommended browser version: Internet Explorer11+/ Firefox27+/ Chrome33+

Installation Steps

1. Right click the step.exe in the installation package, select Run as Administrator: This is the Environmental testing tool, can check out whether your computer conforms to the installation standards of the software.

Note:
- Before installing, please disable antivirus software in the system.
- If the % SystemRoot % \ system32 does not exists in the environment variable path, please add.
- When ports occupied, please make modifications.

If there is anomaly detection, the interface will give corresponding tip:

2. If there is no anomaly detection, click [Continue]:

3. Click [Next]:

4. Select I accept the agreement, click [Next]:

End-user Software License Agreement

License:
ZKTeco, hereby, licenses you the right of use of the software application, upon your acceptance of the below conditions: Except for the authorized actions by the terms and conditions in this End-user Software License Agreement (Agreement), no applications, utilizations, duplications, modifications, renting, or transference of any part of the software system shall be practiced.

You must guarantee that:
1. this system shall be applied to one machine only;
2. for back-up or document management purposes, you shall produce a duplication, which is in a readable format for the machine, of this system;
3. you shall transfer this system and the Agreement to the third party, only upon the third party's acceptance of the terms and conditions of the Agreement. If any transference is made, the original documents, all related documents, and all duplications of the documents shall be transferred to the third party. Any untransferred document and its duplications shall be completely destroyed and eliminated;
4. you shall apply this system to multi-user condition or Internet system, only upon meeting one of the below pre-requisites:
    it is proclaimed in writing that this system may be applied to multi-users condition or Internet system; or
    License of use has been purchased for all nodes and end node of this system.

You must guarantee that:
1. you shall not re-transfer the license of this system;
2. you shall not perform any type of reverse engineering, disassembly, or de-compilation;
3. you shall not duplicate, or deliver this system or any part of this system, except for authorized actions in writing by the terms and conditions in this agreement.

Your license is automatically terminated, if you transfer this system, or any part of this system, or duplication of this system, or any part of the duplication of this system to the third party.

Copyrights and Ownerships of this system:
The names of this systems and all its duplications co-exist with the company stated in the CD-ROM or in this system. This system and all its related documents own copyright, and are under legal protection of the "Copyright Law of People's Republic of China" and "World Intellectual Property Organization Copyright Treaty". You are not entitled to delete the Copyright Proclamation from this system, and shall guarantee to duplicate the Copyright Proclamation for this system. You shall agree to prevent and stop any form of illegal duplications of this system and all its related documents.

After-sale Warranty:
We offer warranty that, under normal usage, in 90 consecutive days after purchase, no manual or material defects shall be present in the software carrier. In case defects are certified, our complete responsibility shall be the exchange of purchased software carrier. Any defect caused by accident, misuse, or overuse are not covered by our After-sale Warranty. Exchanged carriers possess the previous remaining period of guarantee, or 30 consecutive days guarantee (if the remaining period of guarantee is less than 30 consecutive days).

Limitations on Our Warranty:

○ I accept the agreement   ○ I do not accept the agreement   < Back   Cancel   Next >

5. Set the port:

Note:

- Web Access Port is used to access the website and Device ADMS port is used to connect to the device. you can define by yourself except 21,80,6380 and 5432.

- Device ADMS Port is 8088 by default. If the port is occupied, please modify but avoid occupied port. It can't be same with database port 5432 and redis port 6380 and 21,80.

- Check Exception for adding firewall box to avoid preventing the program running.

6. Click [Next] to select installation path:

Note:

- You can select the installation path as you wish.

- The software requires at least 500M space, please ensure the installation path you selected has enough space.

7. Database page, only support PostgreSQL.

8. Click [Next] to set backup document path:

Note:

- Software will scan the disk then find the largest available drive space to create a folder named SecurityDBBack.

- You can select the installation path as you wish.

9. Click [Next]:

Note: Click [Cancel] to quit the installation, click [Back] to reset the settings.

10. Click [Install] to start installing:

11. Waiting for the software to complete the installation, click [Finish], restart the server to complete the installation.

Completing the ZKBioAccess Setup Wizard

○ Yes, restart the computer now
○ No, I will restart the computer later

[Finish]